




DWC multi functions remote control

1. Panel printing introduction



HI: High level input

LOW: Low level input

AUX: AUX input

OPTIC: Optical input

BTA: Bluetooth input

USB: USB flash disk audio input

Memory1.2.3.4: DSP presets

Source: Input source switch

Memory: DSP Presets switch

Previous and next song: only for Bluetooth audio and USB audio input

Knob in the middle: Main level & Group level control, Mute.

2. Knob LED indicator:



- After connect to the amplifier, the LED will light up **blue color** when the amplifier is turn on. This is **Main (all channels) output level control mode**
- Push the knob to **Mute** (LED changed to **red color**), push again back to Main level output control.
- Long push the knob until the LED change to **Green** for **Group level control mode**
It only control the output level of the channels that chosen on the software as SLAVE
If no channel is chosen as SLAVE on dsp setup, there'll be no function at this mode.